





Meter 0 0


😏 SknyLoft Creation -- Select more sketches to add or click Generate to complete the skin/loft 🛛 3 Sketches















































#### E: exercise5\_BoatHull - DesignModeler \_ 7 🗙 File Create Concept Tools View Help Plane6 • \* protle\_4 • 5 Generate @Store Topology Extr Extrude @Revolve &Sweep &Skin/Loft @Thin/Surface &Blend - &Chamfer &Point Parameters Tree Outline # Graphics E: exercise5\_BoatHull A profile\_1 → YZPlane → YZPlane Planes → Plane5 → Plane5 → Plane6 → @ profile\_4 ₩ → @ Skn2 ↓ Thin1 ₩ → @ 1Part, 1Body Sketching Modeling Details View - Details of Thin1 Thin/Surface Selection Type Thin1 Faces to Remove 3 Faces Geometry 3 Faces Direction Inward FD1, Thickness (>=0) 0.05 m 1.000 (m) **Click Here to Continue** Ready Meter 0 0

# What Have We Learned?



- How to Extrude a sketch
- · How to Revolve a sketch
- · How to Sweep along a path
- · How to Sweep around a path
- · How to set a Parameter
- · How to Skin/Loft sketches
- · How to Thin/Surface an object

#### **Additional Topics of Interest**

@ 2009 ANSVS. Inc. All rights reserved.

Parameterizing DM Models

5

ANSYS, Inc. Proprietary